



#102 Robert's Dry Goods Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Chimneys

Lightly sand bottom edge of chimney backs (102-5 & 102-6) until flat. Sand or file the smooth sides of chimney backs and molded-in chimney fronts so back and front fit tight and flush with each other. Glue together. When glue is dry, sand tops of chimneys flat.

Entry Doors

Remove "tabs" (necessary for molding purposes) from tops and bottoms of entry door (102-9) and entry side panels (102-8) by cutting in the indentations with hobby knife being careful to not damage the door frames. See Fig. 1. Note that both entry side panels have a shallow angle on one edge and a deeper angle on the other edge. Glue shallow angled edges to entry door. While glue is still flexible on the resulting "entry assembly", glue deeply angled edges to back of the columns by the opening on front wall (102-1). See Exploded View Drawing.

