



## #103 Cutting's Scissor Co. Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

### Chimneys

Lightly sand bottom edge of chimney back (103-8) until flat. Sand or file the smooth sides of chimney back and molded-in chimney fronts so back and front fit tight and flush with each other. Glue together. When glue is dry, sand tops of chimney flat.

### Overhang Roof

Cut 2 overhang roofs from styrene sheet. Cut 103-9 (styrene roof material) to about 3 1/4" x 1" and a second overhang roof (not shown) to about 4 3/4" x 1". Position 103-9 as shown. Position the second overhang roof above loading dock doors on wall that isn't shown. Glue roofs with a slight downward pitch and place them high enough for vehicles and rolling stock to clear beneath.

### Roof Supports

Note that wall 103-2 has a molded-in ledge that serves as a support for roof 103-7.

