



#104 B. Moore Catalog/Showroom Instructions

Please follow the HO scale General Instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before building your kit.

Chimneys

Lightly sand bottom edge of chimney backs (104-6) until flat. Sand or file the smooth sides of chimney backs and molded-in chimney fronts so back and front fit tight and flush with each other. Glue together. When glue is dry, sand tops of chimneys flat.

