



#106 Laube's Linen Mill Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Chimney

Lightly sand bottom of chimney (106-8) and glue to roof after roof installation.

Roof Overhang

Cut styrene roof material to about 4 1/4" x 1" for roof overhang (106-6). Cut or file two notches to clear pilasters. Trim length to fit between pilasters as shown. Glue to wall above dock level loading doors. Place it with a slight downward pitch and high enough for vehicles and rolling stock to clear.

