



#109 Townhouse #1 Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before building your kit.

Chimneys

Lightly sand bottom edge of chimneys (109-7) flat and glue to top of side walls.

Stoop

Glue stoop (109-8) in place.

