



## #112 City Cab Co. Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

### Chimney

Lightly sand bottom edge of chimney back until flat (112-12). Sand or file the smooth side of chimney back and molded-in chimney front so back and front fit tightly and are flush with each other. Glue together. When glue is dry, sand the top of chimney until flat.

### Walls

Glue the four two-story walls together. Glue the four one-story walls together. Note that wall 112-8 touches the sill on wall 112-3. Cut off part of the sill so wall 112-8 will fit flush to wall 112-3. Glue the two assemblies together as shown.

