



#114 Townhouse Flats 3 Fronts Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Fronts

Remove any excess sprue material from top and bottom edges of fronts by filing or sanding until smooth. Do not sand into cornice, brick or stone details. Arrange fronts as they will appear when finished.

If you want the fronts to butt tightly, wherever a detailed edge of one front meets the edge of another front, sand adjoining edges to remove beveling.

Suggestions

Use flats to simulate additional buildings without occupying the layout space that complete, three-dimensional buildings do. Black paper may be placed behind finished flats to create the illusion of occupancy.

