



## #116 Carr's Parts Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

### Chimney

Sand the smooth sides of chimney halves (116-7) so they fit flush with each other; glue together. When completely dry, file or sand to and bottom, keeping edges flat and square so no rounding occurs. Glue chimney to the top of roof after installation of roof.

To remove "tabs" (necessary for molding purposes) from tops and bottoms of entry door (116-5), lightly cut in the indentations by making several passes with a hobby knife (X-Acto). Be careful to not damage the door frames. See Fig. 1. To assemble door side panels see General Instructions.

### Entry Doors

