



#118 1ST National Bank Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Chimney

Sand the smooth sides of chimney halves (118-7) so they fit flush with each other, glue together. When completely dry, file top and bottom and square. Glue chimney to top of the roof after roof installation.

