



#119 M.T. Arms Hotel Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

Chimney

Glue chimney halves together. When glue is dry, sand or file bottom of chimney flat and square. Glue to top of roof after roof installation.

Window Sprues

To remove window sprues, we recommend using Fiskars Diagonal Cutters. If not available, use hobby knife with chisel blade. Lay part on flat surface, face up. Set hobby knife with chisel blade on side of sprue. Use small hammer to tap hobby knife and cut through each side of sprue from front only. Be careful not to cut window sash. Clean sides with file (Fig. 1).

