



## #121 Seymour Block Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

### Chimneys

Lightly sand bottom of chimney backs until flat (120-5). Sand or file the smooth sides of chimney back sand molded-in chimney fronts so back and front fit tightly and are flush with each other. Glue

together. When glue is dry, sand tops of chimneys flat.

### Entry Doors

To remove "tabs" (necessary for molding purposes) from tops and bottoms of entry door (120-6), lightly cut in the indentations by making several passes with a hobby knife (X-Acto). Be careful to not damage the door frames. See Fig. 1. To assembly door side panels see General Instructions.

