



## #201 Schultz's Garage Instructions

Please follow the HO scale general instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before beginning to build your kit.

### Chimney

Lightly sand bottom of chimney, retaining the angle so chimney sits straight when glued to roof. Glue to roof after roof installation.

### Doors and Windows

Remove doors and windows from sprue. Paint them

as desired (following General Instructions). Cut clear window material to cover backs of window frames. Glue to window frames taking care that glue does not squeeze onto clear material where visible. "Flash" occurring inside of openings may have to be removed by scraping lightly with a hobby knife (X-Acto) to ensure a proper fit. Glue door and window assemblies in place.

### Roof

To assemble gable roof, see enclosed #201 Roof Assembly Instructions.

