



WARNING: Sharp objects. Choking Hazard! Small parts. Not intended for children under 3 yrs. Adult supervision required.

AVERTISSEMENT: Objet pointu. Danger d'étranglement! Petites pièces. Pas recommandé pour les enfants de moins de 3 ans. Supervision d'un adulte requise.

CAUTION: Cutting tools recommended. Use with care.

Conforms to Health Requirements of ASTM D4236

MODELING AND CARE INFORMATION: This kit suggests the use of products which may stain or cause damage. Take care to cover project area and clothing appropriately. Follow recommendations for use and clean up.

#2020 Pam's Pet Shop Instructions

Follow the enclosed HO scale General Instructions for #100 and #200 series kits. The General Instructions will refer to the drawings and instructions included with this kit. Read through all instructions before beginning construction on your kit.

Chimneys

Lightly sand bottom edge of all Chimney Backs (202-6) flat. Sand or file the smooth sides of Chimney Backs and molded-in Chimney fronts so back and front fit tight and flush. Glue together. When glue is dry, sand tops of Chimneys flat.

Building Fronts

Sand or file the bottom edge of 202-1A and the top edge of 202-1B so top and bottom fit tight and flush. Glue together.

Doors and Windows

Remove Doors and Windows from Sprue. Paint them as desired (following General Instructions). Cut Clear Window Material to cover backs of window frames. Glue to window frames taking care that glue does not squeeze onto Clear Material where visible. "Flash" occurring inside of openings may have to be removed by scraping lightly with a hobby knife. Glue Door and Window assemblies in place.

Entry Doors

Be careful to not damage the door frames when removing Entry Door (202-7) from Sprue. Note that both Entry Side Panels (202-8) have the same angle on both edges. While glue is still flexible on the resulting "Entry Assembly," glue edges to back of columns by opening on Front Wall.

