



#204 Walker Building Instructions

Please follow the HO scale General Instructions for #100 and #200 Series Kits which are enclosed in this kit. You will be referred to the drawings and notes printed here. Please read through all instructions before building your kit.

Chimneys

Lightly sand bottom edge of chimney backs (204-5). Sand or file the smooth sides of chimney backs and molded-in chimney fronts so back and front fit tight and flush with each other. Glue together. When glue is dry, sand tops of chimneys flat.

Building Front

Sand or file the bottom edge of 204-B, the top and

bottom edge of 204-1 and the top edge of 204-A so the three pieces fit tightly, and are flush with each other. Glue together.

Doors & Windows

Remove doors and windows from sprue. Paint them as desired (following general instructions). Cut clear window material to cover backs of window frames. Glue to window frames, taking care that glue does not squeeze onto clear material where visible. "Flash" occurring inside window and door openings may have to be removed by scraping lightly with a hobby knife (X-Acto) to ensure a proper fit. Glue door and window assemblies in place.

