

ROOMETTES

BANFIELD STREET FLATS #01-114-01 AND COMBO R4377

INSTRUCTIONS

1. REMOVE ONE OF THE ROOMS FROM THE CARDSTOCK SHEET WITH A SHARP HOBBY KNIFE. DO NOT CUT THE DOTTED LINES. THEY ARE FOR FOLDING. SAVE THE SCRAP CARDBOARD FOR REFERENCING ROOM LOCATIONS USING THE TEXT PRINTED ON THEM.
2. CAREFULLY BEND THE WALLS, FLOOR AND CEILING INWARD TO CREATE A BOX. DO NOT OVERBEND THEM!
3. BEND AND GLUE THE LEFT AND RIGHT WING TABS UNDER THE FLOOR. USE A POPSICLE STICK OR SIMILAR TOOL TO CAREFULLY APPLY PRESSURE ON THE FLOOR OVER EACH WING TO SET THE GLUE.
4. FLIP THE ROOM OVER AND GLUE THE LEFT AND RIGHT WING TABS OVER THE TOP OF THE CEILING.
5. BEND THE TABS LABELLED "GLUE TO WALL" AT A RIGHT ANGLE OUT OF THE ROOM. SET THE ROOM ASIDE TO DRY.
6. ASSEMBLE THE OTHER ROOMS IN A SIMILAR MANNER.
7. CHECK ALL GLUE JOINTS TO MAKE SURE THEY ARE SOLID BEFORE PROCEEDING. TEST FIT THE ROOMS. IF YOU HAVE ASSEMBLED YOUR BUILDING ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS THEY SHOULD FIT EASILY. IF YOU FIND THEY FIT TOO TIGHT VERTICALLY YOU CAN REMOVE SOME OF THE WALL-MOUNT TAB MATERIAL WITH SCISSORS FOR ADDITIONAL CLEARANCE.
8. TO PREVENT LIGHT LEAKAGE, SPREAD A BIT OF GLUE INTO THE PERFORATED SEAMS ON THE CORNERS OF THE ROOM FROM THE OUTSIDE. THIS WILL ALSO MAKE THE JOINTS STRONGER.
9. YOU CAN MAKE 3-DIMENSIONAL BEDS FOR THE HEADBOARDS BY CUTTING BLOCKS FROM DENSE STYROFOAM AND PAINTING THEM. GLUE THEM TO THE FLOOR.
10. USE YOUR KNIFE TO REMOVE THE CEILING PLUGS AND INSTALL PROVIDED LEDS, FASTENING THEM IN PLACE WITH GOOD QUALITY TAPE OR GLUE.
11. STARTING WITH THE UPPER FLOORS GLUE THE ROOMS TO THE WALLS, BEING CAREFUL NOT TO GET GLUE ON YOUR CLEAR WINDOW MATERIAL.
12. PLUG THE LED HARNESS INTO YOUR WOODLAND SCENICS® JUST PLUG® OR NCE ILLUMINATOR MODULE. SIT BACK AND ENJOY YOUR EFFORTS!

THIS IS NOT A TOY.
NOT SUITABLE FOR CHILDREN
UNDER 14 YEARS OF AGE.