

Look for these other HO scale Landmark Structures Building Kits at your local hobby shop.

- PF5181 Planters Feed and Seed Supply
- PF5182 Main Street Mercantile
- PF5183 Sonny's Super Service
- PF5184 Sicken Tire Company
- PF5185 O'Leary Dairy Distribution
- PF5186 Country Cottage
- PF5187 Woodland Station
- PF5188 D's Diner
- PF5189 Public Pavillion
- PF5190 Rustic Barn
- PF5192 Windmills
- PF5193 Deuce's Bike Shop
- PF5194 Mo Skeeters Bait & Tackle
- PF5195 Buzz's Sawmill
- PF5196 Corner Porch House



Just Plug® LIGHTING SYSTEM

The Just Plug Lighting System is a complete, quick and easy way to add realism to new and existing layouts and other projects. No electrical knowledge or special tools needed. Just plug and you're done! Individual bulb brightness can be controlled, and special window film eliminates the need for building interiors. The modular design allows for easy expansion, and Just Plug works for all scales.



It's as easy as placing
a light and setting
your building on top.

LANDMARK STRUCTURES®

HO SCALE
1:87
BUILDING KIT

FRESH MARKET

PF5180

Model the local flavor of a bustling downtown layout. The Fresh Market presents a vintage storefront ready to tell the story of an era steeped in culinary tradition. Use Dry Transfer Decals to advertise a family bakery, a father/son butcher shop or another hometown taste.



MODELING AND CARE INFORMATION

This kit suggests the use of materials that may stain or cause damage. Take care to cover project area and clothing appropriately. Follow recommendations for use and cleanup.

CAUTION: Cutting tools recommended. Use with care.

We make every effort to ensure our kits are manufactured complete. However, if this kit is missing a part, please make note of the kit name, number and missing part. Contact the Woodland Scenics Sales and Customer Service Department at PO Box 98, Linn Creek, MO 65052, 573-346-5555 or sales@woodlandscenics.com.





WOODLAND SCENICS®

XPF5180INST K3 ©2016 O C O

FRESH MARKET

Building Kit Contents

- Building Shell
- 2 sets of Sprues including Details and Roof
- Pre-printed Window Treatments
- Clear Window Material
- Dry Transfer Decals
- 2 pcs of Blackout Paper



7. Detail Installation cont.




Fig. 7e

Roof (Fig. 7e): Hatch (21),
Vent 2x (22)

8. Install Blackout Paper

- Cut two sheets of Blackout Paper, each measuring $5\frac{3}{8}$ in W x $3\frac{1}{8}$ in H.
- Lay the two sheets on top of each other and cut a notch halfway up both sheets (Fig. 8a).
- Assemble as shown (Fig. 8b).
- Insert into building (Fig. 8c).
- Place a drop of glue at each corner to hold in place.




Fig. 8a




Fig. 8b




Fig. 8c

Tips and Techniques

Concrete Mortar

- To add a realistic mortar-look, apply a **Concrete Mortar Wash** to brickwork (formula below). Lay building flat so the wash will spread evenly. Avoid Decals and dab on small amounts of Mortar Wash until desired look is achieved. Sponge off excess.

Concrete Mortar Wash: 1-part paint (color suggestion: concrete, aged concrete, etc.), 9-parts rubbing alcohol, 7-parts water, 2-drops liquid dish soap


Weathering

- Age decals by scoring and chipping with a hobby knife.
- **Airbrushing Technique:** Lightly spray thinned flat black paint to select areas. Add more where discoloration can occur (near windows, chimneys, etc.).
- **Chalk:** Rub dark pastel chalk (color suggestion: gray, black, brown, etc.) on sandpaper to create chalk dust. Using a paintbrush, dab chalk dust where discoloration can occur.

7. Detail Installation


- Follow the detailed schematic for installing Details. Attach using Cyanoacrylate glue.
- NOTE:** The following Details do not have placement holes: Wooden Barrel (8), Gumball Machine (9), Bench (10), Ice Machine (11), and Window Board (13). Extra Part: Light 1x (4)

Fig. 7a




Front (Fig. 7a): Large Awning 2x (2), Small Awning (3), Light 3x (4), Signboard (5), Fruit Stand (6), Barrels Under Fruit Stand (7), Wooden Barrel (8), Gumball Machine (9), Bench (10)

Fig. 7b




Right Side (Fig. 7b): Ice Machine (11), Ladder (12), Window Board (13)

Fig. 7c




Back (Fig. 7c): Light (4), Dumpster (14), Wooden Crate (15), Handcart (16), Trashcan and Trash (17)

Fig. 7d



Left Side (Fig. 7d): Electric Meter and Junction Box (18), Cola Machine (19), Cola Bottle Collector (20), Light (4)



Before You Begin

- Read through instructions.
- Collect additional supplies.
- Check kit contents and verify Details.
- Cover project area with newspaper.

TIP! To assist in assembly, refer to exploded-view illustration on back of box.

Additional Supplies


- | | |
|--|---|
| <input type="checkbox"/> Cyanoacrylate Glue (super glue) | <input type="checkbox"/> Painting Tools |
| <input type="checkbox"/> Paints (acrylic and/or enamel)* | <input type="checkbox"/> Tweezers |
| <input type="checkbox"/> Primer* | <input type="checkbox"/> Newspaper |
| <input type="checkbox"/> Hobby Knife | <input type="checkbox"/> Scissors |
| <input type="checkbox"/> Fine Grade Sandpaper | <input type="checkbox"/> Burnisher or Dull Pencil |

NOTE: Always allow glue to set before moving to the next step. Avoid contact with detail on parts.

*Contact your local hobby shop for recommendations. _____


1. Building and Detail Preparation

- Remove any mold flash from Building Shell using a hobby knife and sandpaper. (Fig. 1a)
- Wash Building Shell, Roof and Details (on sprue) in warm, soapy water using a mild detergent. Rinse and let dry.
- Remove Details from sprue using a hobby knife (or flush cutting shears). **NOTE:** Do not remove placement posts. (Fig. 1b)
- Sand off any mold flash and parting lines from Details. **NOTE:** Do not sand placement posts.




2. Chimney Assembly

- Glue on Chimney 4x ①.
- NOTE:** Make sure the angle on the bottom of the Chimney is pointing down toward the back of the building. (Fig. 2a)





3. Roof Installation

- Install Roof by tilting it down under the Chimneys and sliding it toward the front of the building. (Fig. 3a)
- NOTE:** The lettering on the Roof should be on the underside and the two small holes toward the back.
- Glue in place. (Fig. 3b)



4. Prime and Paint


- NOTE:** Do not prime or paint placement posts.
- Apply a thin coat of primer to Building and Details.
 - Allow to dry.
 - Paint Building and Details, as desired.
 - Allow to dry.
 - Optional:** Add a realistic mortar-look (see *Tips and Techniques*, page 6).



TIP: Taping Details (unexposed side down) to loops of masking tape on a piece of cardboard makes priming and painting easier. (Fig. 4a and Fig. 4b)

5. Window Details

- You have two options for window details: Clear Window Material or Pre-printed Window Treatments*.
- Remove protective flim before installation.
- TIP:** To make it easier to use the Clear Window Material, place it over Pre-printed Window Treatments sheet and trace cut-lines with a fine-tip permanent marker.
- Cut preferred window details, as desired.
 - Place Building on its front face with the bottom toward you. (Fig. 5a)
 - Center window detail over window on inside of Building.
 - Carefully dab a small amount of glue around edges of window detail. (Fig. 5a)
 - Repeat for each set of window openings.



*Position printed side of window treatment toward inside of Building.

6. Decal Application

- NOTE:** Test-fit signage before applying Dry Transfer Decals. You don't want your sign upside-down!
- Cut out Decals, leaving a slight edge. (Fig. 6a)
 - Grasp edge of Decal with tweezers and avoid handling the back.
 - Position in desired location and rub over entire Decal area with burnisher or dull pencil. (Fig. 6b)
 - Carefully lift away carrier sheet.
 - Place backing paper over Decal and rub again for maximum adhesion.

